




Octagon One

Desk Light

Operating Manual



ginkgo

DESIGN - QUALITY - TIME


Thank you for your purchase of Octagon One from Gingko.
This box includes one unit Octagon One Desk Light, a USB Charging Lead, a Product Warranty Card and a Product Operating Manual.

Power Switch Instruction

You may need to recharge this product fully for the first time if it can't be turned on. Please follow the charging instructions in this manual.

1. The power switch is touch control. See below diagram for the touch control area.

touch control area on the power switch



2. There are 4 different brightness levels on this product and this can be changed on the touch control switch.

3. Gently touch the touch control area quickly to turn the product on to level 1, the next 3 touches will adjust the brightness from level 2 to level 4 and the 5th touch will turn the light off. To turn the light off at any time you can hold your finger on the touch control area for more than 2 seconds.

4. The blue LED light on the touch control area will flash once in every 3 seconds when it's turned on, 2 times on the second touch, 3 times on the 3rd touch and 4 times on the 4th touch.

Product Charging Instruction

The product is powered by an in-built lithium-ion rechargeable battery and the battery life on a full charge can last between 4-48 hours depending on how you use it.

1. This product can be recharged by connecting the USB charging lead to any USB port in a computer, laptop, or any USB charging adapter like our smartphone USB charger. The output of the USB adapter can't exceed 5V.

2. The charging time is approximately 3-5 hours.

3. the blue LED indication light on the touch control area will constantly flash while it is being recharged. The blue LED light will stay on to indicate that it's fully charged.



WARNING:

PLEASE DO NOT USE ANY MORE THAN 5V USB ADAPTER TO RECHARGE THIS PRODUCT AS THIS MAY CAUSE DAMAGE TO THIS PRODUCT GRADUALLY.

Product Display Angles

This product can be displayed in 3 different angles as below diagrams



Product Care Instruction

1. If the touch control power switch doesn't work when it's powered by battery, it usually can be resolved by plugging it to your USB charger adapter or any USB port in a computer or laptop.
2. Please recharge this product at least once a month when possible
3. Please only clean this product by soft dampened cloth when needed.
4. Please do not use this product if you notice any wire or spare parts exposed outside after an accident drop and report this to the manufacturer immediately.
5. Please do not use any more than 5V USB charging adapter to recharge this product.

If you have any other queries about the operation of this product, please email to support@ging-ko.co.uk for assistance.

Copyright © Gingko Electronics Ltd

All rights reserved 版权保护, 违者必究



www.ging-ko.co.uk

www.gingkoelectronics.com

Printed in China