# MI SQUARE TM Pocket Bluetooth Speaker Ouick User Manual

ENGLISH

DEUTSCH

FRANCAIS

**NEDERLANDS** 

ITALIANO

ESPAÑOL



#### Packina List



It includes one unit MI SQUARE speaker, one USB charging cable and one user manual.

### **Product Operations**



\*\*ON/OFF: press and hold it for 3 seconds to turn it on or off Green light flashing: Bluetooth searching Green light stays on: Successfully paired



Turn on the Bluetooth on your device in setting to search your nearby Bluetooth devices;
Select 'Gingko Mi Square' to get paired
(It may take up to a minute to find the device or sometimes you may need to turn off and turn back on the bluetooth function on your device to be able to find the Mi Square)





#### Music Playing

Play / Pause: press once
The device will turn itself off if it hasn't been used in
5 minutes.

		5V Micro USB Charging Port
4.	0	Approx 1.5-2 hours to be fully recharged; please fully charge it for first time use; Red light on: in charging;

Red light off: fully charged

(You may connect the USB charging lead to any 5V USB charger to charge the product, such us a smartphone charger or a computer USB port.

#### **TWS Pairing Instructions**

1 1

This product has TWS (true wireless stereo) technology built in so it allows you to enjoy the stereo quality sound when you have have two MI Square Speakers. Please follow the below instructions to get them paired.

- Turn on both speakers by pressing and holding down the power button for 3 seconds and make sure both of the speakers haven't been paired with any bluetooth device first.
- Should get paired in 15 seconds with a beep sound.
- 3. If the pairing is not successfully, turn off the both devices and try it again by following the above instructions. When paired, the main speaker indication light will flash and the other device light will stay on.
- 4. To unpair the devices, double click the power button.
- 5. The two devices will be automatically paired once they have been turned on If they have been paired before.
- 6. Press the power button once on either speaker will pause or restart the playing.

#### **Product Care Notices**

- 1. It's recommended to use this product in a humidity environment between 35% and 85% due to the product is made of natural solid wood material.
- 2. A heavy drop may damage the wooden case and product itself.
- 3. Any natural wood grain or slight wood knot on the case is not a product fault.
- 4. You may use a wet cloth to clean the wood case, but do not use water to do the cleaning directly.
- 5. Please keep the product away from any long and direct sunlight exposure as this may change the wood colour or cause other damages
- to the wood case gradually. 6. Please only use 5V USB charging adapter to charge this product. Any higher rated votage charging adapter may gradually damage the
- product or shorten the battery life eventually.



## www.ging-ko.co.uk Copyright © Gingko Electronics Ltd

All rights are registered and protected Alle Rechte sind eingetragen und geschützt Todos los derechos están registrados y protegidos

> support@ging-ko.co.uk Printed in China







